



**Sundström Safety AB**  
 Västergatan 2, S-340 14 Lagan  
 1-888-732-3500



**SR 83 WELDING HOOD**

**TYPE C CONTINUOUS FLOW SUPPLIED AIR RESPIRATOR**

THESE RESPIRATORS ARE APPROVED ONLY IN THE FOLLOWING CONFIGURATIONS						
RESPIRATOR COMPONENTS						
TC-	Protection <sup>1</sup>	Facepiece	Regulator	Alternate hoses / connectors		Cautions & Limitations <sup>2</sup>
		SR 83	SR 349	H03-35xx	H03-36xx	
19C-428	SA/CF	X	X	X	X	ABCDEJM NOS

**1. PROTECTION**

**CF-Continuous Flow**  
**SA-Supplied Air**

**2. CAUTIONS AND LIMITATIONS**

- A - Not for use in atmospheres containing less than 19.5 percent oxygen.
- B - Not for use in atmospheres immediately dangerous to life or health.
- C - Do not exceed maximum use concentrations established by regulatory standards.
- D - Air-line respirators can be used only when the respirators are supplied with respirable air meeting the requirements of CGA G-7.1 Grade D or higher quality.
- E - Use only the pressure ranges and hose lengths specified in the Use'rs Instructions.
- J - Failure to properly use and maintain this product could result in injury or death.
- M - All approved respirators shall be selected, fitted, used, and maintained in accordance with MSHA, OSHA and other applicable regulations.
- N - Never substitute, modify, add, or omit parts. Use only exact replacement parts in the configuration as specified by the manufacturer.
- O - Refer to User's Instructions, and/or maintenance manuals for information on use and maintenance of these respirators.
- S - Special or critical Use'rs Instructions and/or specific use limitations apply. Refer to Use'rs Instructions before donning.