

Solo Rescue - Quick guide

Wash and rinse temperature, wash time and extra rinse cycles (CE Machines)





Open "Menu mode"

To be able to check and adjust the current settings of your Solo Rescue® you will have to open "Menu mode" on the display on the front of the machine.

- Press the red "STOP" button (#2) and then press button #4 (long program) five (5) times.
- While in "menu mode", use button #3 or #4 to move through the various menu options. The first number in the display indicates the menu number.

Menu 8 - Adjusting the wash temperature*

The temperature can be set to a value between $30^{\circ}-60^{\circ}$ C and the interval can be changed with one (1) degree steps.

- 1. To adjust the wash temperature, press button #5.
- 2. To save the new setting, press the "START" button (#1).
- 3. To exit "menu mode", press the "STOP" button (#2).

Menu 9 - Adjusting the rinse temperature*

The temperature can be set to a value between $30^{\circ}-60^{\circ}\text{C}$ and the interval can be changed with one (1) degree steps.

- 1. To adjust the rinse temperature, press button #5.
- 2. To save the new setting, press the "START" button (#1).
- 3. To exit "menu mode", press the "STOP" button (#2).

Menu 0 - Adjusting the wash time for "Long Program"

The washing time can be set to a value between 5-30 minutes and the interval can be changed with one (1) minute steps.

- 1. To adjust the washing time, press button #5.
- 2. To save the new setting, press the "START" button (#1).
- 3. To exit "menu mode", press the "STOP" button (#2).

Menu 11 – Adding extra rinse cycles

Adjustable range: 1–4 rinse cycles. Dosage pump for rinse/disinfection/defoamer is always activated on first rinse only.

- 1. To adjust the number of rinse cycles, press button #5.
- 2. To save the new setting, press the "START" button (#1).
- 3. To exit "menu mode", press the "STOP" button (#2).

* Important!

Always follow the temperature recommendations from your equipment manufacturer. Washing in the wrong temperature may cause damage to your equipment and may void all warranty.

Email: sea.enquiries@sea.com.au | Website: www.sea.com.au