



User Instructions Threaded Filter Adaptor TA1

Adaptor TA1 is intended for connecting Sundstrom or SEA clip-in filters to breathing protection devices with EN 148-1 standard thread.

Fitting of filter

The filter is to be fitted in the adaptor with the arrow pointing towards the adaptor. Check carefully that the filter edge engages the internal circumferential slot. Next, fit the pre-filter 221 by means of the pre-filter holder. The adaptor with the filter fitted is then to be threaded onto the respirator.

Check before using

Each time the adaptor is to be used, check first that it is clean and undamaged. A damaged adaptor is to be discarded immediately. The adaptor is firmly assembled and cannot be dismantled.

Maintenance and storage

The adaptor is to be cleaned daily after being used. Clean it with Sundstrom cleaning cloth. As needed, the adaptor can be cleaned with a brush and hot water. Use ordinary detergents and flush afterwards with clean water.

NOTE: Do not use solvents when cleaning. The adaptor should preferably be stored in a clean and dry place at room temperature.

Warning

Adapter TA1 is not intended for use with compressed air attachments.