

SmallTalk ST2-P

Voice communication device for S.E.A.SMF full face respirator



SEA AMERICA

11 Business Park Drive
Branford, CT 06405, USA

Phone: [+1] 203-483 9483
Fax: [+1] 203-483 6633
TollFree: 1888-732 3500

email: sea.america@sea.com.au

SEA EUROPE

Storgatan 64
S-331 31 Värnamo
SWEDEN

Phone: [+46] (0)370-69 34 40
Fax: [+46] (0)370-179 79

email: sea.europe@sea.com.au

SEA AUSTRALIA

North Shore Business Park
35/1 Jubilee Avenue
Warriewood NSW 2102
AUSTRALIA

Phone: [+61] (0)2 9910 7500
Fax: [+61] (0)2 9979 5364
TollFree: 1800-655 129

email: sea.australia@sea.com.au

www.sea.com.au

User Instructions

100252-03A



SmallTalk ST2-P User Instructions

The SmallTalk ST2-P is an accessory for S.E.A. SMF full face respirators. When used in accordance with these instructions, the respirator continues to provide full protection.

To fit battery (fig A):

- Remove the battery cover by pressing down and sliding it out of the unit.
- Insert a 9V battery, with polarity as per markings inside battery compartment.
- While holding the battery in place, slide battery cover back in place.

To attach SmallTalk to the S.E.A. SMF full face respirator (fig. B):

- Remove the spark guard cover (if fitted) from the speech channel.
- Fit the flexible microphone holder to the speech channel, with the cable pointing out to the *left* of the mask.
- Snap the microphone holder onto the speech channel. Ensure that the cable comes over the filter.
- Don the respirator and attach the SmallTalk to your *right* pocket. This is to minimise feedback effects.
- Switch on the SmallTalk and adjust the volume to the desired level while speaking.

Note: if feedback (whistling) occurs, turn the volume down slightly. Feedback may occur in enclosed areas.

Cleaning and maintenance:

- The SmallTalk ST2-P is water resistant. However, do not subject it to running water, and do not immerse it in water.
- To clean, wipe with clean, damp cloth. Do not use solvents.
- Avoid exposing the microphone to water. Wipe with clean, damp cloth.
- If unit accidentally comes in contact with water, remove battery, wipe it, shake out any water and wipe inside battery compartment, including contact surfaces.

