



Chemical Testing Results
MICROCHEM® 3000

ACRONYMS KEY

—	Not reported
MDPR	Minimum detectable permeation rate
BDT	Breakthrough detection time (first appearance after the MDPR)
BT 0.1	Normalised breakthrough detection time at 0.1 µg/cm ² /min
BT 1.0	Normalised breakthrough detection time at 1.0 µg/cm ² /min
EN Class	Based on the mean BT (or lowest if the mean is not available) at 1.0µg/cm ² /min according to ISO 6529
CP	Cumulative permeation after 480 min. If no permeation detected, then reported as <[MDPR x 480]
CPT	Time to cumulative permeation of 150 µg/cm ²
PR	Steady state permeation rate. If not reached then maximum permeation rate for the duration of the test is reported. If no permeation is detected then reported as <MDPR

EN Class	Normalised Breakthrough Time in minutes
0	Immediate (no class)
1	≥ 10
2	≥ 30
3	≥ 60
4	≥ 120
5	≥ 240
6	≥ 480 (or >540)

CAS Number	Chemical Name	MDPR µg/cm ² /min	BDT	BT 0.1µg/cm ² /min	BT 1.0µg/cm ² /min	EN Class EN 14325	CP µg/cm ²	CPT µg/cm ² /min	CP Class	PR µg/cm ² /min
108-24-7	Acetic Anhydride	≤0.05	-		>480	6	-	-	-	<1.0
67-64-1	Acetone	≤0.08	4	4	28	1	-	-	-	-
75-05-8	Acetonitrile	≤0.08	Imm	Imm	<6	0	-	-	-	-
79-06-1	Acrylamide	-	-		>480	6	-	-	-	<1.0
79-10-7	Acrylic Acid	-	-		>480	6	-	-	-	<1.0
107-18-6	Allyl Alcohol	0.02	7	77	>480	6	51.2	>480	6	0.13
7664-41-7	Ammonia (Gas, 1 atmos.)	≤0.05	Imm	1	3	0	-	-	-	-
1341-49-7	Ammonium Hydrogen Fluoride (Saturated)	0.06	>480	>480	>480	6	<28.8	>480	6	<0.06
1336-21-6	Ammonium Hydroxide (20% w/w)	0.05	<6	<6	>480	6	64	>480	6	0.56
1336-21-6	Ammonium Hydroxide (25% w/w)	0.05	<6	<6	>480	6	79	>480	6	-
17804-35-2	Benlate®	-	-		>480	6	-	-	-	<1.0
71-43-2	Benzene	-	-		2	0	-	-	-	-
98-09-9	Benzene Sulphonyl Chloride	-	-		>480	6	-	-	-	<1.0
100-44-7	Benzyl Chloride	-	-		16	1	-	-	-	-
7726-95-6	Bromine	-	-		2	0	-	-	-	-
71-36-3	Butanol, n-	-	-		>480	6	-	-	-	<1.0
141-32-2	Butyl Acrylate, n-	-	-		16	1	-	-	-	-
75-15-0	Carbon Disulphide	-	-	Imm	Imm	0	-	-	-	-
7782-50-5	Chlorine (Gas, 1 atmos.)	≤0.05	9	9	10	1	-	-	-	-
7782-50-5	Chlorine Water (satd.)	-	-		2	0	-	-	-	-
79-11-8	Chloroacetic Acid (79% w/w)	0.076	>480	>480	>480	6	<37	>480	6	<0.076
79-04-9	Chloroacetyl Chloride	-	-		36	2	-	-	-	-
107-07-3	Chloroethanol, 2-	-	-		>480	6	-	-	-	<1.0
67-66-3	Chloroform	-	-		Imm	0	-	-	-	-
107-94-8	Chloropropionic Acid, 3- (Liquid, 50 °C / 122 °F)	0.02	10	37	>480	6	237	318	5	0.6
1333-82-0	Chromium Trioxide (50% w/w)	0.09	>480	>480	>480	6	<43.2	>480	6	<0.09
1319-77-3	Cresols, mixed	<1.0	-		>480	6	-	-	-	<1.0
107-06-2	Dichloroethane, 1,2-	-	-		4	0	-	-	-	-
156-60-5	Dichloroethylene, trans-1,2-	-	-		2	0	-	-	-	-
75-09-2	Dichloromethane (Methylene Chloride)	≤0.08	Imm	Imm	Imm	0	-	-	-	-
68334-30-5	Diesel	-	-		15	1	-	-	-	-
60-29-7	Diethyl Ether	-	-		Imm	0	-	-	-	-
109-89-7	Diethylamine	≤0.08	Imm	Imm	Imm	0	-	-	-	-
367-25-9	Difluoroaniline, 2,4-	-	-		>480	6	-	-	-	<1.0
624-49-7	Dimethyl Fumarate	0.05	>480	>480	>480	6	<24	>480	6	<0.05
77-78-1	Dimethyl Sulphate (DMA)	-	-		>480	6	-	-	-	<1.0
124-40-3	Dimethylamine (40% w/w)	-	-		>480	6	-	-	-	<1.0
5683-33-0	Dimethylaminoopyridine, 2-	-	-		57	2	-	-	-	-
68-12-2	Dimethylformamide, N,N-	-	-		>480	6	-	-	-	<1.0
106-89-8	Epichlorohydrin	0.05	-	12	>480	6	-	-	-	0.8
75-08-1	Ethanthiol	0.05	<1	<1	1	0	ND	ND	ND	High
141-43-5	Ethanolamine	0.07	>480	>480	>480	6	<33.6	>480	6	<0.07
141-78-6	Ethyl Acetate	≤0.08	Imm	Imm	3	0	-	-	-	-
107-21-1	Ethylene Glycol	-	-		>480	6	-	-	-	<1.0
149-57-5	Ethylhexanoic Acid, 2-	-	-		>480	6	-	-	-	<1.0
7705-08-0	Ferric Chloride (45%)	0.03	>480	>480	>480	6	<14.4	>480	6	<0.03
50-00-0	Formaldehyde (37%)	-	-		>480	6	-	-	-	<1.0
64-18-6	Formic Acid (90%)	-	-		>480	6	-	-	-	<1.0
64-18-6	Formic Acid (98% w/w)	0.02	>480	>480	>480	6	<9.6	>480	6	<0.02
98-01-1	Furfural	-	-		>480	6	-	-	-	<1.0
Mixture	Gardoclean S 5174 (Analysis of potassium hydroxide component)	0.04	>480	>480	>480	6	<19.2	>480	6	<0.04
142-82-5	Heptane, n-	≤0.08	Imm	Imm	Imm	0	-	-	-	-
124-09-4	Hexamethylene Diamine, 1,6-	-	-		>480	6	-	-	-	<1.0
822-06-0	Hexamethylene Diisocyanate	<0.1	-	>480	>480	6	<48	>480	6	<0.1
110-54-3	Hexane, n-	0.09	Imm	Imm	Imm	0	-	-	-	-
7803-57-8	Hydrazine Monohydrate (98%, containing hydrazine, 64-65% w/w)	<1.0	>480	>480	>480	6	-	-	-	<1.0
10035-10-6	Hydrobromic Acid (48% w/w)	-	-		>480	6	-	-	-	<1.0
7664-39-3	Hydrofluoric Acid (49% w/w)	0.06	378	407	>480	6	33.7	>480	6	0.17

Important: Breakthrough time alone is not sufficient to determine how long a garment may be worn once the garment has been contaminated. Safe wear time may be longer or shorter depending on numerous other factors, including the toxicity, exposure conditions and permeation behaviour of the substance.

Safety Note

All chemical tests and breakthrough times given relate to laboratory tests on fabrics only. Seams and closures may have lower breakthrough times, particularly when worn or damaged. It is the user's responsibility to select an appropriate garment, gloves, boots and other equipment for the particular use. The user shall be responsible for determining how long the garment can be worn for the particular use and whether it can be suitably cleaned for re-use. Microgard Limited does not give any warranties or make any representations about its garments other than those contained in the official literature supplied by Microgard Limited with each garment.



Menu

Data Entry




GAG Visor

Choose Language



PDF Options





Chemical Testing Results
MICROCHEM® 3000

ACRONYMS KEY

—	Not reported
MDPR	Minimum detectable permeation rate
BDT	Breakthrough detection time (first appearance after the MDPR)
BT 0.1	Normalised breakthrough detection time at 0.1 µg/cm ² /min
BT 1.0	Normalised breakthrough detection time at 1.0 µg/cm ² /min
EN Class	Based on the mean BT (or lowest if the mean is not available) at 1.0µg/cm ² /min according to ISO 6529
CP	Cumulative permeation after 480 min. If no permeation detected, then reported as <[MDPR x 480]
CPT	Time to cumulative permeation of 150 µg/cm ²
PR	Steady state permeation rate. If not reached then maximum permeation rate for the duration of the test is reported. If no permeation is detected then reported as <MDPR

EN Class	Normalised Breakthrough Time in minutes
0	Immediate (no class)
1	≥ 10
2	≥ 30
3	≥ 60
4	≥ 120
5	≥ 240
6	≥ 480 (or >540)

CAS Number	Chemical Name	MDPR µg/cm ² /min	BDT	BT 0.1µg/cm ² /min	BT 1.0µg/cm ² /min	EN Class EN 14325	CP µg/cm ²	CPT µg/cm ² /min	CP Class	PR µg/cm ² /min
7664-39-3	Hydrofluoric Acid (62-64% in urea)	-	-	-	41	2	-	-	-	-
7664-39-3	Hydrofluoric Acid (71-75% w/w)	0.03	2	13	273	5	NR	264	5	1.48
7647-01-0	Hydrogen Chloride (Gas, 1 atmos.)	≤0.05	Imm	Imm	8	0	-	-	-	-
74-90-8	Hydrogen Cyanide (HCN)	0.01	3	<3	<3	0	-	113	3	>1.0
7722-84-1	Hydrogen Peroxide (35% w/w)	-	-	-	>480	6	-	-	-	<1.0
7722-84-1	Hydrogen Peroxide (50% w/w)	-	-	-	>480	6	-	-	-	<1.0
7553-56-2	Iodine	-	-	-	>480	6	-	-	-	<1.0
67-63-0	Isopropyl Alcohol	-	-	-	>480	6	-	-	-	<1.0
7439-97-6	Mercury	0.05	>480	>480	>480	6	<24	>480	6	<0.05
67-56-1	Methanol	0.05	imm	4	>480	6	-	364	5	0.59
625-45-6	Methoxyacetic Acid, 2-	-	-	-	>480	6	-	-	-	<1.0
74-88-4	Methyl Iodide	-	-	-	>480	6	-	-	-	<1.0
872-50-4	Methyl-2-pyrrolidone, N-	-	-	-	>480	6	-	-	-	<1.0
98-95-3	Nitrobenzene	0.05	41	48	>480	6	-	-	-	-
75747-77-2	Octave®	-	-	-	>480	6	-	-	-	<1.0
8014-95-7	Oleum (20% w/w Sulphur Trioxide)	0.05	8	16	60	3	29 (70 min)	70 (29 µg)	3	High
8014-95-7	Oleum (30% w/w Sulphur Trioxide)	0.05	<6	7	21	1	21 (28 min)	28 (21 µg)	1	High
144-62-7	Oxalic Acid (10%)	0.06	>480	>480	>480	6	-	>480	6	<0.06
Mixture	Oxilan 9810 (Analysis of ethanol component)	0.01	>480	>480	>480	6	<4.8	>480	6	<0.01
N/A	Oxilan Additive 9905 (Mixture)	0.09	>480	>480	>480	6	<43.2	>480	6	<0.09
92062-35-6	Paraffin	-	-	-	25	1	-	-	-	-
7601-90-3	Perchloric Acid (30% w/w)	≤0.05	>480	>480	>480	6	-	-	-	≤0.05
8006-61-9	Petrol (Unleaded)	-	-	-	2	0	-	-	-	-
108-95-2	Phenol (Liquid, 45 °C / 113 °F)	0.01	Imm	Imm	4	0	-	152	4	2.75
108-95-2	Phenol (liquified, approx. 90% w/w with water)	0.021	>480	>480	>480	6	<10	>480	6	<0.021
Mixture	Phenol/Benzyl Alcohol 25:5	-	-	-	>480	6	-	-	-	<1.0
7664-38-2	Phosphoric Acid (≥85% w/w)	0.05	>480	>480	>480	6	<24	>480	6	<0.05
10025-87-3	Phosphorus Oxchloride	-	-	-	9	0	-	-	-	-
10026-13-8	Phosphorus Pentachloride	-	-	-	>480	6	-	-	-	<1.0
85-44-9	Phthalic Anhydride (Liquid, 135 °C / 275 °F)	-	-	-	>480	6	-	-	-	<1.0
Mixture	Piranha solution (sulphuric acid 96% w/w:hydrogen peroxide 30% w/w)	0.02	Imm	1	>480	6	-	-	-	-
75-98-9	Pivalic Acid	-	-	-	>480	6	-	-	-	<1.0
25322-68-3	Polyethylene Glycol 200	-	-	-	>480	6	-	-	-	<1.0
1310-58-3	Potassium Hydroxide (30%)	0.04	>480	>480	>480	6	<19.2	>480	6	<0.04
1310-58-3	Potassium Hydroxide (80-86% w/v)	0.04	>480	>480	>480	6	<19.2	>480	6	<0.04
123-38-6	Propionaldehyde	0.05	<1	<1	2	0	-	33	2	-
110-86-1	Pyrrolidine	0.05	7	8	17	1	N.D	N.D	-	>2
85-00-7	Realone®	-	-	-	>480	6	-	-	-	<1.0
52315-07-8	Ribcord®	-	-	-	>480	6	-	-	-	<1.0
38641-94-0	Roundup®	-	-	-	>480	6	-	-	-	<1.0
7681-38-1	Sodium Bisulphate (40%)	-	-	-	>480	6	-	-	-	<1.0
7647-14-5	Sodium Chloride	-	-	-	>480	6	-	-	-	<1.0
143-33-9	Sodium Cyanide (satd.)	-	-	-	>480	6	-	-	-	<1.0
7681-49-4	Sodium Fluoride (satd.)	-	-	-	>480	6	-	-	-	<1.0
1310-73-2	Sodium Hydroxide (40% w/w)	0.068	>480	>480	>480	6	<32.6	>480	6	<0.068
1310-73-2	Sodium Hydroxide (50% w/w, 80 °C / 176 °F)	0.031	>480	>480	>480	6	<26	>480	6	<0.031
1310-73-2	Sodium Hydroxide (50% w/w)	0.068	>480	>480	>480	6	<33	>480	6	<0.068
7681-52-9	Sodium Hypochlorite Solution (14.5% available chlorine)	0.041	>480	>480	>480	6	<19.7	>480	6	<0.041
7681-52-9	Sodium Hypochlorite Solution (5% available chlorine)	0.041	>480	>480	>480	6	<19.7	>480	6	<0.041
124-41-4	Sodium Methsulfate (30%)	-	-	-	>480	6	-	-	-	<1.0
16893-85-9	Sodium Silicofluoride (satd.)	-	-	-	>480	6	-	-	-	<1.0
100-42-5	Styrene	0.04	Imm	Imm	Imm	0	-	3	0	199
7664-93-9	Sulphuric Acid (≥98% w/w)	<0.1	-	-	>480	6	-	-	-	<0.1
7664-93-9	Sulphuric Acid (50% w/w, 80 °C / 176 °F)	0.021	>480	>480	>480	6	<10	>480	6	<0.021
7664-93-9	Sulphuric Acid (95-96% w/w)	≤0.05	>480	>480	>480	6	<24.5	>480	6	<0.05
306-83-2	SUVA HCFC-123 (1,1-Dichloro-2,2,2-trifluoroethane)	-	-	-	251	5	-	-	-	-
1634-04-4	t-Butyl Methyl Ether	<0.1	-	-	1	0	-	-	-	-
109-99-9	Tetrahydrofuran	≤0.08	Imm	Imm	Imm	0	-	-	-	-

Important: Breakthrough time alone is not sufficient to determine how long a garment may be worn once the garment has been contaminated. Safe wear time may be longer or shorter depending on numerous other factors, including the toxicity, exposure conditions and permeation behaviour of the substance.

Safety Note

All chemical tests and breakthrough times given relate to laboratory tests on fabrics only. Seams and closures may have lower breakthrough times, particularly when worn or damaged. It is the user's responsibility to select an appropriate garment, gloves, boots and other equipment for the particular use. The user shall be responsible for determining how long the garment can be worn for the particular use and whether it can be suitably cleaned for re-use. Microgard Limited does not give any warranties or make any representations about its garments other than those contained in the official literature supplied by Microgard Limited with each garment.





Chemical Testing Results
MICROCHEM® 3000

ACRONYMS KEY

—	Not reported
MDPR	Minimum detectable permeation rate
BDT	Breakthrough detection time (first appearance after the MDP)
BT 0.1	Normalised breakthrough detection time at 0.1 µg/cm ² /min
BT 1.0	Normalised breakthrough detection time at 1.0 µg/cm ² /min
EN Class	Based on the mean BT (or lowest if the mean is not available) at 1.0µg/cm ² /min according to ISO 6529
CP	Cumulative permeation after 480 min. If no permeation detected, then reported as <[MDPR x 480]
CPT	Time to cumulative permeation of 150 µg/cm ²
PR	Steady state permeation rate. If not reached then maximum permeation rate for the duration of the test is reported. If no permeation is detected then reported as <MDPR

EN Class	Normalised Breakthrough Time in minutes
0	Immediate (no class)
1	≥ 10
2	≥ 30
3	≥ 60
4	≥ 120
5	≥ 240
6	≥ 480 (or >540)

CAS Number	Chemical Name	MDPR µg/cm ² /min	BDT	BT 0.1µg/cm ² /min	BT 1.0µg/cm ² /min	EN Class EN 14325	CP µg/cm ²	CPT µg/cm ² /min	CP Class	PR µg/cm ² /min
75-59-2	Tetramethylammonium Hydroxide (20% w/w)	0.07	>480	>480	>480	6	<33.6	>480	6	<0.07
7719-09-7	Thionyl Chloride	-	-	-	Imm	0	-	-	-	-
1758-73-2	Thiourea Dioxide (satd.)	-	-	-	>480	6	-	-	-	<1.0
7550-45-0	Titanium Tetrachloride	0.02	Imm	Imm	7	0	-*	35	2	11.1
108-88-3	Toluene	≤0.08	Imm	Imm	Imm	0	-	-	-	-
584-84-9	Toluene-2,4-diisocyanate	-	-	-	>480	6	-	-	-	<1.0
95-53-4	Toluidine, o-	-	-	-	>480	6	-	-	-	<1.0
76-03-9	Trichloroacetic Acid (59 °C / 138 °F)	-	-	-	>480	6	-	-	-	<1.0
79-01-6	Trichloroethylene	-	-	-	2	0	-	-	-	-
121-44-8	Triethylamine	-	-	-	Imm	0	-	-	-	-
76-05-1	Trifluoroacetic Acid	-	-	-	>480	6	-	-	-	<1.0
2177-18-6	Vinyl Acrylate	-	-	-	3	0	-	-	-	-
108-38-3	Xylene, m-	-	-	-	2	0	-	-	-	-
106-42-3	Xylene, p-	0.01	Imm	Imm	Imm	0	-	<3	0	218
7699-45-8	Zinc Bromide (satd.)	-	-	-	>480	6	-	-	-	<1.0

Important: Breakthrough time alone is not sufficient to determine how long a garment may be worn once the garment has been contaminated. Safe wear time may be longer or shorter depending on numerous other factors, including the toxicity, exposure conditions and permeation behaviour of the substance.

Safety Note

All chemical tests and breakthrough times given relate to laboratory tests on fabrics only. Seams and closures may have lower breakthrough times, particularly when worn or damaged. It is the user's responsibility to select an appropriate garment, gloves, boots and other equipment for the particular use. The user shall be responsible for determining how long the garment can be worn for the particular use and whether it can be suitably cleaned for re-use. Microgard Limited does not give any warranties or make any representations about its garments other than those contained in the official literature supplied by Microgard Limited with each garment.



Menu

Data Entry



GAG Visor

Choose Language



PDF Options

