

SmallTalk ST2-F

Voice communication device for S.E.A. full face respirator



SEA AMERICA

11 Business Park Drive
Branford, CT 06405, USA

Phone: [+1] 203-483 9483
Fax: [+1] 203-483 6633
TollFree: 1888-732 3500

email: sea.america@sea.com.au

SEA EUROPE

Storgatan 64
S-331 31 Värnamo
SWEDEN

Phone: [+46] (0)370-69 34 40
Fax: [+46] (0)370-179 79

email: sea.europe@sea.com.au

SEA AUSTRALIA

North Shore Business Park
35/1 Jubilee Avenue
Warriewood NSW 2102
AUSTRALIA

Phone: [+61] (0)2 9910 7500
Fax: [+61] (0)2 9979 5364
TollFree: 1800-655 129

email: sea.australia@sea.com.au

User Instructions

100208-03B

www.sea.com.au



SmallTalk ST2-F User Instructions

The SmallTalk ST2-F is a communication accessory for the S.E.A. full face mask respirator. When used in accordance with these instructions, the respirator continues to provide full protection.

To fit battery (fig A):

- Remove the battery cover by pressing down and sliding it out of the unit.
- Insert a 9V battery, with polarity as per markings inside battery compartment.
- While holding the battery in place, slide battery cover back in place.

To attach SmallTalk to the respirator (fig. B):

- Remove the valve cover of the respirator.
- Thread the microphone and microphone cable of the ST2-F valve cover into the aperture *above* the filter fitting. (This may require some patience.)
- Snap the valve cover onto the respirator.
- Thread on the filter securely.
- Don the respirator and clip the SmallTalk ST2-F to your pocket, directly to your belt, or onto the optional belt clip (HSE) (fig. C).
- Do not place the loudspeaker unit too close to the microphone. This is to prevent feed-back effects.
- Switch on the SmallTalk ST2-F and adjust the volume to the desired level.

Cleaning and maintenance:

- The SmallTalk ST2-F is water resistant. However, do not subject it to running water, and do not immerse it in water.
- To clean, wipe with clean, damp cloth. Do not use solvents.
- Avoid exposing the microphone to water. Wipe with clean, damp cloth. Do not block vent holes on outside of microphone housing.
- If unit accidentally comes in contact with water, remove battery, wipe it, shake out any water and wipe inside battery compartment, including contact surfaces.

